

IMPROVEMENTS[®]

No tools required. Simply secure and tighten provided cable ties.



Locate the side of the ottoman with the three horizontal support bars. Using the cable ties provided, secure these three bars together with two cable ties placed approximately 8" from each end.



Repeat the steps from side 1 on the opposite hinged side and secure the two horizontal metal bars. Be sure to loop the cable ties around both metal bars and tighten.

Tighten each cable and tuck the end of the tie into the frame of the ottoman under the top cushion.

By securing each hinged side with the cable ties, the ottoman bed is unable to unfold and safe to use as an ottoman.



Please make sure the cable ties each have a warning label attached to them stating "Warning: Do Not Remove." Should you have any additional questions, please call us at 1-800-985-6044, Monday to Friday, 9 am to 5 pm (EST) or visit us at www.improvementscatalog.com. To see a video version of these instructions, please go to <http://www.youtube.com/watch?v=nArElerKSYM>